


SERIE 145

Chapa de 15 / 10


SOPORTES en página 127




145 10
Se sirve sin Soportes
PESO: 9,5 kg.



145 10 1
17 Soportes herramientas mecánico.
1 Soporte 141 0 10 141 0 14 141 0 17
141 0 18 141 0 19
3 Soportes 141 0 01 141 0 02 141 0 03
141 0 04 PESO: 2,4 kg.




Fijación de Soportes para Herramientas



145 13
Se sirve sin Soportes
PESO: 12 kg.




145 13 1
21 Soportes herramientas mecánico.
1 Soporte 141 0 10 141 0 14 141 0 17
141 0 18 141 0 19
4 Soportes 141 0 01 141 0 02 141 0 03
141 0 04 PESO: 2,7 kg.



145 15
Se sirve sin Soportes
PESO: 13 kg.



145 15 1
27 Soportes herramientas mecánico.
1 Soporte 141 0 10 141 0 12 141 0 14
141 0 17 141 0 18 141 0 19
141 0 23
5 Soportes 141 0 01 141 0 02 141 0 03
141 0 04 PESO: 3,2 kg.



145 18
Se sirve sin Soportes
PESO: 17 kg.



145 18 1
35 Soportes herramientas mecánico.
1 Soporte 141 0 10 141 0 12 141 0 14
141 0 17 141 0 18 141 0 19
141 0 23
7 Soportes 141 0 01 141 0 02 141 0 03
141 0 04 PESO: 3,4 kg.



145 20
Se sirve sin Soportes
PESO: 19 kg.



145 20 1
43 Soportes herramientas mecánico.
1 Soporte 141 0 10 141 0 12 141 0 14
141 0 17 141 0 18 141 0 19
141 0 23
9 Soportes 141 0 01 141 0 02 141 0 03
141 0 04 PESO: 3,6 kg.

SOLUCIONES



145 20 + 136 20 C2